



UPDATE TO INSTALLATION INSTRUCTIONS FOR PART NUMBER 6020.

Mirror part number affected: 6020.

Vehicle Model – Model Year 2004 onwards- Change to vehicle wire colors for connection of turn signal and clearance lights.

Refer to step 23 in instructions enclosed in mirror carton.

For owners of model year 2004 onward vehicles only.

Clearance Light Yellow Wire:

Attach both of the yellow wires to the 'white with yellow trace'. This wire can be found going into connector B (refer to step 23 in instructions).

Turn Signal Red Wires:

Attach the left hand (driver's side) red extension wire to the 'white with green trace'. This wire can be found going into connector A (refer to step 23 in instructions).

Attach the right hand (passenger's side) red extension wire to the 'white with light brown trace'. This wire can be found going into connector A (refer to step 23 in instructions).

